

FITTING INSTRUCTIONS

Heads – rendered buildings

1. Fix a render bead along the top of the window.
2. Fix a treated timber batten to the face of the building to the thickness of the render base coat.
3. Base coat render the building and when dry fix the DYNNAMIXS mounting strip(s) to the timber. Ensure that the mounting strip(s) are centred over the window and are level.
4. Offer the head up to the DYNNAMIXS mounting Strip(s) and ensure the head is level. If the head is not level slacken the fixing screws and level the mounting strip(s).
5. Apply a bead of DYNNAMIXS adhesive to the inside of the fixing slot on the back of the head.
6. Offer the head up to the DYNNAMIXS mounting strip(s) and fully push home.
7. Allow DYNNAMIXS adhesive to cure and then apply the top coat of the render system to the building (ensure that the head is protected during this operation).
8. When the render system has hardened fully seal the head using a high quality silicone sealant.

