

FITTING INSTRUCTIONS

Quoins – rendered buildings

- 1 Offer 4 Quoin unit up to the corner of the building after the render base coat has been applied and allowed to cure, mark the fixing hole positions and remove the Quoin unit.
- 2 Drill the marked fixing hole positions using a 6mm masonry drill and insert the supplied plastic expansion plugs.
- 3 Apply a bead of DYNNAMIX adhesive to the rear flat faces of the quoins and then fix to the building using the 4x40mm screws supplied and the pre installed plastic expansion plugs.
- 4 Offer the next 4 Quoin unit up to the corner of the building, mark the fixing hole positions and remove the Quoin unit.
- 5 Drill the marked fixing hole positions using a 6mm masonry drill and insert the supplied plastic expansion plugs.
- 6 Apply a bead of DYNNAMIX adhesive to the rear flat faces of the quoins and the inside of the overlap joint, then screw fix to the building using the pre installed plastic expansion plugs
- 7 Repeat operations 4, 5 and 6 until the full corner is complete
- 8 Ensure that the quoins are protected before the render top coat is applied and when hardened seal with a high quality silicone sealant.

