

FITTING INSTRUCTIONS

Heads – brick faced buildings

1. Fix DYYNAMIX mounting strip(s) to the face of the building using the 4x40mm screws and plugs supplied (6mm masonry drill required). Ensure that the mounting strip(s) are centred over the window and are level.
2. Offer the head up to the DYYNAMIX mounting strip(s) and ensure the head is level. If the head is not level slacken the fixing screws and level the mounting strip(s)
3. Apply a bead of DYYNAMIX adhesive to the inside of the fixing slot on the back of the head
4. Offer the head up to the DYYNAMIX mounting strip(s) and fully push home.
5. Allow DYYNAMIX adhesive to cure and then fully seal using a high quality silicone sealant

